



Any driver entering Portland Container Repair to drop equipment **MUST** stop at the appropriate yard office to properly check their equipment in. Drivers must also call or stop at the office to check equipment out **before** leaving the facility.

INBOUND INSPECTION LANE AND YARD RULES

All drivers must adhere to the following safety rules while in the inspection lanes.

ALL GATE AND INSPECTION AREAS ARE SAFETY ZONES DUE TO THE TRAFFIC AROUND IT AND PEOPLE BEING IN AND OUT OF TRUCKS WORKING.

- If there is a line of trucks on the road waiting to enter, you must wait your turn in line – even if you are picking up only. Once you're first in line, you may call ahead to get called out for your load.
- Speed in the yard and at the gate is 5 MPH maximum.
- **High visibility vests or jackets are required by all drivers while working inside PCR gates or yard areas.**
- There are 2 inbound inspection lanes closest to the office/building. Once you pick a lane, do not back up and switch lanes. Maximum 2 trucks per lane.
- Once you have stopped in the inspection area you must set your brakes, shut your engine down, and get out of your vehicle. Accompany the gate inspector throughout the inspection. **Do not move your vehicle until instructed by the gate inspector.**
- Inform your inspector of any equipment issues. The interchange process is an important part of documenting defects and also helps in getting repairs done.
- Unlock all twist locks and open the container door, when applicable, for inspection.
- Once you receive your inspection slip and your truck is first in line, proceed into the office.
- Be prepared with all the necessary information to pick up or drop off equipment. You must know what you need and be able to communicate it with staff.
- Talking on the phone/Bluetooth headsets and smoking are prohibited at the inbound lanes.
- Pedestrians and lifts have right of way. Listen for lift horns and do not cut through stacks.
- Repeat violators will be banned.

The most important safety feature in any truck is the professional driver!

Office: 503-286-5961 option 1 CB channel 22

Please reach out to CY@pdxcontainer.com to obtain a yard map if needed.